

GREEN SLOPE

Application Instructions:

- 1** Open bucket and remove- Bag, brush, gloves and paper.
- 2** Place bag over bucket, empty contents in bag- Remove resin quart.
- 3** Prior to mixing, ensure surface is clean, dry and damage free. For maximum adhesion, apply 297-X Primer prior to application.
- 4** Once you're ready to mix, place gloves on and empty resin into bag. Use brush to remove ALL of the resin into the bag.
- 5** Give contents a quick mix with your hands and knead bag to combine the product thoroughly. Hint- Mix should be done within 15 mins. While kneading, allow space in bag for product to tumble.
- 6** Dump product into low areas and spread with trowel or tool. Compact product to provide a solid form. Scrape and compact to level or create slope.
- 7** Repeat for desired results.
- 8** Once product has dried (12-24hrs), apply 2 coats of Tucson Rubberized Coating's topcoat Premium products to ensure product longevity.



How to Video Guide



ADDITIONAL QUESTIONS? CONTACT US



(520) 293-7000



6351 S Tucson Blvd, Tucson, AZ. 85706



www.rubberized.com

